


# 17. LIGHTS/INSTRUMENTS/SWITCHES

---

## ELECTRICAL EQUIPMENT LAYOUT



# 17. LIGHTS/INSTRUMENTS/SWITCHES

---

ELECTRICAL EQUIPMENT LAYOUT.....	17-0	HANDLEBAR SWITCHES.....	17-3
SERVICE INFORMATION.....	17-1	STOP SWITCHES.....	17-5
TROUBLESHOOTING.....	17-1	HORN.....	17-5
HEADLIGHT.....	17-2	FUEL GAUGE.....	17-5
FRONT TURN SIGNAL LIGHT.....	17-2	FUEL UNIT.....	17-6
POSITION/REAR TURN SIGNAL LIGHT...	17-2	AUTO BYSTARTER.....	17-6
IGNITION SWITCH.....	17-3	INSTRUMENTS.....	17-8

## SERVICE INFORMATION

### GENERAL INSTRUCTIONS

- An electric tester is needed to measure or test the electric equipment.
- Be sure to use fuses and bulbs of the same specifications to avoid damage of electrical equipment.
- After installation of each switch, a continuity check must be performed. A continuity check can usually be made without removing the part from the motorcycle.

### TROUBLESHOOTING

#### Lights do not come on and horn does not sound when ignition switch is “ON”

- Faulty ignition switch
- Fuse burned out
- Weak battery
- Burned bulb
- Faulty switch
- Faulty horn
- Poorly connected, broken or shorted wire

#### Fuel gauge pointer does not move

- Faulty fuel gauge
- Faulty fuel unit
- Poorly connected, broken or shorted wire

#### Engine starts but stalls during idling

- Faulty auto bystarter
- Faulty auto bystarter resistor
- Poorly connected or broken wire
- Clogged carburetor

#### Fuel gauge pointer does not register correctly


- Faulty fuel gauge
- Faulty fuel unit
- Faulty fuel unit float

# 17. LIGHTS/INSTRUMENTS/SWITCHES

## HEADLIGHT


### BULB REPLACEMENT

Remove the front cover. (⇒2-4)  
Remove the rubber boot from the bulb socket.  
Remove the bulb socket by turning it counter-clockwise.  
Remove the bulb for replacement.  
Install a new bulb, aligning the groove on the bulb socket with the tab on the bulb.  
Install the bulb socket.  
Install the rubber boot.  
Install the front cover. (⇒2-4)




### HEADLIGHT REMOVAL

Remove the front cover. (⇒2-4)  
Remove the six screws attaching the headlight.  
Remove the headlight.  
The installation sequence is the reverse of removal.  
After installation, adjust the headlight beam. (⇒3-9)



### FRONT TURN SIGNAL LIGHT


Remove the front cover. (⇒2-4)  
Remove the front turn signal bulb socket and replace the bulb.  
The installation sequence is the reverse of removal.



### POSITION LIGHT/REAR TURN SIGNAL LIGHT

#### BULB REPLACEMENT

Remove the rear cover. (⇒2-2)  
Remove the two screws to remove the position light/rear turn signal light shell.  
Remove the bulb sockets and replace the bulb.  
The installation sequence is the reverse of removal.



Screws

# 17. LIGHTS/INSTRUMENTS/SWITCHES

## IGNITION SWITCH

### INSPECTION

Remove the front cover. (⇒2-4)  
 Disconnect the ignition switch wire coupler.  
 Check for continuity between the wire terminals.


Color Position	Black	Red	Black/ White	Green
LOCK			○ — ⊖	
OFF			○ — ⊖	
ON	○ — ⊖			

### Replacement

Remove the two mounting bolts to remove the ignition switch holder.  
 Remove the two screws to remove the ignition switch for replacement.



Ignition Switch Coupler




Ignition Switch Holder

## HANDLEBAR SWITCHES

### HEADLIGHT SWITCH INSPECTION

Remove the handlebar front and rear covers. (⇒2-4)  
 Disconnect the headlight switch wire couplers. Check for continuity between the wire terminals.

	HL	CL	TL	PO	RE
OFF		○ —			⊖
N		○ — ⊖	⊖	⊖	
P		○ — ⊖	⊖	⊖	
N	○ — ⊖	⊖	⊖		
H	○ — ⊖	⊖	⊖		
Color	Blue/ White	Yellow	Brown	Brown/ White	Pink




# 17. LIGHTS/INSTRUMENTS/SWITCHES


## STARTER SWITCH

	ST	E
FREE		
PUSH	○ ———	⊖
Color	Yellow/Red	Green

Headlight Switch



Starter Switch




## HORN SWITCH

	HO	BATZ
FREE		
PUSH	○ ———	⊖
Color	Light Green	Black




Horn Button




## TURN SIGNAL SWITCH

	R	L	WR
L		○ ———	⊖
N			
R	○ ———		⊖
Color	Light Blue	Orange	Gray




Turn Signal Switch



## DIMMER SWITCH

	HL	HI	LO	PASS
PASS		○ ———		⊖
LO	○ ———		⊖	
N	○ ———	⊖ ———	⊖	
HI	○	○ ———		
Color	Blue/White	Blue	White	Black

Dimmer Switch




# 17. LIGHTS/INSTRUMENTS/SWITCHES

## STOP SWITCH

### INSPECTION


Remove the handlebar front cover. (⇒2-4)  
Disconnect the front stop switch wire coupler.

Check for continuity between the wire terminals when the front brake lever is applied. The switch is normal if there is continuity.



## HORN INSPECTION

Remove the front cover. (⇒2-4)  
Disconnect the horn wire coupler.  
The horn is normal if it sounds when a 12V battery is connected across the horn wire terminals.




Green

## FUEL GAUGE

### INSPECTION

Remove the rear right side cover. (⇒2-2)  
Disconnect the fuel gauge wire connector.  
Turn the ignition switch ON.  
Connect the green and yellow/white wires and the fuel gauge needle should move from E to F.  
Connect the green and blue/white wires and the fuel gauge needle should move from F to E.




Yellow/White

## FUEL UNIT

### REMOVAL

Remove the met-in box. (⇒2-3)  
Remove the rear right side cover. (⇒2-2)  
Disconnect the fuel unit wire connector.  
Remove the fuel unit.

\* Be careful not to bend or damage the fuel unit float arm.



Fuel Unit Connector


# 17. LIGHTS/INSTRUMENTS/SWITCHES

## INSPECTION

Measure the resistance between the fuel unit wire terminals with the float at upper and lower positions.


RESISTANCES Unit:  $\square$

Color	Float	Upper		Lower	
	G_ Y/W		35_	45	480_
G_ L/W		480_	520	35_	45
Y/W_ L/W		480_	520	480_	520



The installation sequence is the reverse of removal.

- \*
  - Install the fuel unit by aligning the groove on the fuel unit with the tab on the fuel tank.
  - Align the arrow on the fuel unit retainer with the arrow on the fuel tank.




## AUTO BYSTARTER

### AUTO BYSTARTER INSPECTION

Remove the rear right side cover. ( $\Rightarrow$ 2-2)  
 Disconnect the auto bystarter wire connector.  
 Measure the resistance between the yellow and green/black wire terminals.

**Resistance:** 10 $\square$  max.

- \* Perform this operation when the engine is cold.




Auto Bystarter

### RESISTOR INSPECTION

Remove the front cover. ( $\Rightarrow$ 2-4)  
 Disconnect the green/black and green wires and measuring the resistance between the wire terminals.

**Resistance:** 5 $\square$  max.

If the needle remains at “•”, it indicates that the resistor is faulty and must be replaced.



Auto Bystarter Resistor

# 17. LIGHTS/INSTRUMENTS/SWITCHES

## INSTRUMENTS

### BULB REPLACEMENT

Remove the front cover. (⇒2-4)  
Remove the bulb socket and replace the bulb.  
The installation sequence is the reverse of removal.

### INSTRUMENTS REPLACEMENT


Remove the handlebar front cover. (⇒2-4)  
Remove the handlebar rear cover. (⇒2-4)  
Disconnect the right and left handlebar switches wire couplers.  
Disconnect the speedometer cable.  
Remove the instrument bulb sockets  
Disconnect the three fuel gauge wires.  
Remove the instrument wire clamp screw.

Remove the three screws attaching the instruments to the handlebar rear cover.  
Remove the instruments.


Instruments



Bulb Socket  
Switch Couplers    Bulb Socket    Switch Couplers



Fuel Gauge Wires    Clamp    Speedometer Cable  
Handlebar Rear Cover




Screws

# 17. LIGHTS/INSTRUMENTS/SWITCHES

## DISASSEMBLY


Remove the screws to disassemble the instruments.



Bulb Socket

## ASSEMBLY/INSTALLATION

The assembly and installation sequence is the reverse of removal.



Fuel Gauge Wires

Clamp