

TEXT

A.C. GENERATOR INSPECTION	16 - 5	CYLINDER INSTALLATION	7 - 7
A.C. GENERATOR INSPECTION	17 - 4	CYLINDER REMOVAL	7 - 3
AIR CLEANER	3 - 5	DRIVE BELT	3 - 8
AIR CUT-OFF VALVE (A.C.V.)	13 - 12	DRIVE PULLEY	8 - 4
AUTO BYSTARTER INSPECTION/REMOVAL	13 - 11	ELECTRICAL EQUIPMENT LAYOUT	19 - 1
AUTO BYSTARTER INSTALLATION	13 - 14	ENGINE INSTALLATION	5 - 5
BATTERY	16 - 4	ENGINE OIL	3 - 4
BRAKE SYSTEM	3 - 10	ENGINE OIL/OIL FILTER	4 - 3
CABLE & HARNESS ROUTING	1 - 12	ENGINE REMOVAL	5 - 3
CAMSHAFT INSTALLATION	6 - 10	ENGINE SERIAL NUMBER	1 - 1
CAMSHAFT REMOVAL	6 - 4	EXHAUST MUFFLER REMOVAL	2 - 6
CARBURETOR IDLE SPEED	3 - 6	FINAL REDUCTION ASSEMBLY	9 - 6
CARBURETOR INSTALLATION	13 - 17	FINAL REDUCTION DISASSEMBLY	9 - 3
CARBURETOR REMOVAL	13 - 7	FINAL REDUCTION GEAR OIL	3 - 8
CDI UNIT RESISTANCE INSPECTION	17 - 5	FINAL REDUCTION INSPECTION	9 - 3
CHARGING INDICATOR INSPECTION	16 - 7	FLOAT CHAMBER ASSEMBLY	13 - 15
CHARGING SYSTEM LAYOUT	16 - 1	FLOAT CHAMBER DISASSEMBLY	13 - 9
CHARGING SYSTEM	16 - 5	FLOAT LEVEL INSPECTION	13 - 16
CLUTCH SHOE WEAR	3 - 9	FLYWHEEL INSTALLATION	10 - 5
CLUTCH/DRIVEN PULLEY	8 - 8	FLYWHEEL REMOVAL	10 - 3
COOLING SYSTEM TESTING	12 - 4	FRAME COVERS REMOVAL	2 - 3
COOLING SYSTEM	3 - 9	FRONT BRAKE	14 - 8
CRANKCASE ASSEMBLY	11 - 5	FRONT FORK	14 - 17
CRANKCASE SEPARATION	11 - 3	FRONT SHOCK ABSORBER	14 - 14
CRANKSHAFT	11 - 4	FRONT WHEEL	14 - 5
CYLINDER COMPRESSION	3 - 7	FUEL LINE/FUEL FILTER	3 - 3
CYLINDER HEAD ASSEMBLY	6 - 8	FUEL PUMP ASSEMBLY	13 - 19
CYLINDER HEAD COVER INSTALLATION	6 - 11	FUEL PUMP INSPECTION	13 - 19
CYLINDER HEAD COVER REMOVAL	6 - 4	FUEL PUMP INSTALLATION	13 - 20
CYLINDER HEAD DISASSEMBLY	6 - 7	FUEL PUMP REMOVAL/DISASSEMBLY	13 - 18
CYLINDER HEAD INSTALLATION	6 - 9	FUEL SYSTEM	13 - 1
CYLINDER HEAD REMOVAL	6 - 6	FUEL TANK REMOVAL	13 - 20

TEXT

FUEL UNIT	19 - 5	SCHEMATIC DRAWING	11 - 1
HEADLIGHT AIM	3 - 9	SCHEMATIC DRAWING	12 - 1
HEATER WIRING DIAGRAM	19 - 9	SCHEMATIC DRAWING	13 - 2
HORN INSPECTION	19 - 5	SCHEMATIC DRAWING	14 - 1
IGNITION COIL INSPECTION	17 - 3	SCHEMATIC DRAWING	15 - 1
IGNITION SYSTEM LAYOUT	17 - 1	SCHEMATIC DRAWING	2 - 1
IGNITION TIMING	3 - 7	SCHEMATIC DRAWING	5 - 1
INSTRUMENTS	19 - 7	SCHEMATIC DRAWING	6 - 1
KICK STARTER	8 - 15	SCHEMATIC DRAWING	7 - 1
LEFT CRANKCASE COVER	8 - 3	SCHEMATIC DRAWING	8 - 1
LIGHTS	19 - 8	SCHEMATIC DRAWING	9 - 1
LUBRICATION POINTS	1 - 10	SERVICE INFORMATION	10 - 2
LUBRICATION SYSTEM DIAGRAM	4 - 1	SERVICE INFORMATION	11 - 2
MAINTENANCE SCHEDULE	3 - 2	SERVICE INFORMATION	12 - 2
NUTS/BOLTS/FASTENERS	3 - 11	SERVICE INFORMATION	13 - 5
OIL PUMP ASSEMBLY	4 - 6	SERVICE INFORMATION	14 - 2
OIL PUMP DISASSEMBLY	4 - 4	SERVICE INFORMATION	15 - 2
OIL PUMP INSPECTION	4 - 5	SERVICE INFORMATION	16 - 2
OIL PUMP INSTALLATION	4 - 6	SERVICE INFORMATION	17 - 2
OIL PUMP REMOVAL	4 - 4	SERVICE INFORMATION	18 - 2
OPERATION OF CARBURETOR JETS	13 - 3	SERVICE INFORMATION	19 - 2
PISTON INSTALLATION	7 - 7	SERVICE INFORMATION	2 - 2
PISTON REMOVAL	7 - 3	SERVICE INFORMATION	3 - 1
RADIATOR	12 - 4	SERVICE INFORMATION	4 - 2
REAR BRAKE	15 - 3	SERVICE INFORMATION	5 - 2
REAR FORK	15 - 4	SERVICE INFORMATION	6 - 2
REAR SHOCK ABSORBER	15 - 5	SERVICE INFORMATION	7 - 2
REAR WHEEL	15 - 4	SERVICE INFORMATION	8 - 2
REGULATOR/RECTIFIER INSPECTION	16 - 6	SERVICE INFORMATION	9 - 2
RIGHT CRANKCASE COVER INSTALLATION	10 - 6	SERVICE PRECAUTIONS	1 - 4
RIGHT CRANKCASE COVER REMOVAL	10 - 3	SPARK PLUG	17 - 3
SCHEMATIC DRAWING	10 - 1	SPARK PLUG	3 - 5

TEXT

SPECIFICATION	1 - 2	TROUBLESHOOTING	7 - 2
STARTER CLUTCH INSPECTION	18 - 5	TROUBLESHOOTING	8 - 2
STARTER CLUTCH	10 - 4	TROUBLESHOOTING	9 - 2
STARTER MOTOR	18 - 3	VACUUM CHAMBER ASSEMBLY	13 - 16
STARTER RELAY INSPECTION	18 - 6	VACUUM CHAMBER DISASSEMBLY	13 - 7
STARTING SYSTEM LAYOUT	18 - 1	VALVE CLEARANCE	3 - 6
STATOR INSTALLATION	10 - 6	WATER PUMP	12 - 10
STATOR REMOVAL	10 - 3	WHEELS/TIRES	3 - 11
STEERING HANDLEBAR	14 - 4	WIRING DIAGRAM	1 - 17
STEERING HANDLEBAR	3 - 11		
SUSPENSION	3 - 11		
SWITCHES	19 - 3		
TEMPERATURE GAUGE	19 - 6		
THERMOSENSOR	12 - 16		
THERMOSTAT	12 - 17		
THERMOSTATIC SWITCH	19 - 6		
THROTTLE OPERATION	3 - 3		
TOOLS	1 - 9		
TORQUE VALUES	1 - 8		
TROUBLESHOOTING	10 - 2		
TROUBLESHOOTING	11 - 2		
TROUBLESHOOTING	1 - 18		
TROUBLESHOOTING	12 - 2		
TROUBLESHOOTING	14 - 3		
TROUBLESHOOTING	15 - 2		
TROUBLESHOOTING	16 - 3		
TROUBLESHOOTING	17 - 2		
TROUBLESHOOTING	18 - 2		
TROUBLESHOOTING	19 - 2		
TROUBLESHOOTING	2 - 2		
TROUBLESHOOTING	4 - 2		
TROUBLESHOOTING	6 - 3		
